

# **E5\_C TEMPERATURE CONTROLLER**

A Full Lineup of Next-generation Temperature Controllers



» Contribute to Machine Downsizing
 » High-contrast display
 » Easy set-up and operation with a Special Software

realizing

# The new standard in temperature control...


Omron has been an active innovator in temperature control since introducing its first temperature controller in 1967. Now temperature control has taken a giant leap forward with Omron's next generation of controllers – the E5\_C, which set new global standards in the crucial areas of precision, user friendliness and control performance. The E5\_C series will save you time and effort in set-up and operation, while enabling faster and more accurate monitoring/control of your process. The highvisibility display of the new series is also extremely easy to read and virtually eliminates any possibility for human error.

#### **Key features**

- High-contrast, white LCD display visible from large distances and from any angle
- Easy to set up, and operate intuitively via CX-Thermo without power supply
- 50 ms sampling period for fast and precise regulation
- Functions for diagnosis for secure operations (see note 1)
- Useful timer and logic operation functions eliminating the need of a PLC



Note 1: Alarm for loop break or PV change rate, heater burnout or sensor burnout detection



# ... is higher in every respect

#### **Clearer LCD display**

The large, high-contrast, white LCD display contributes to the exceptional clarity and therefore readability of the E5\_C series. The display can be read unambiguously from greater distances and from much wider viewing angles than normal.

#### Easy set-up and operation

Coupled with the autotuning algorithms, which greatly reduce set-up and commissioning time, Omron's CX-Thermo support software has been specially developed for use with the E5\_C series. This enables faster parameter set-up, easier device adjustment and simpler maintenance.

#### Unique performance

Although intrinsic high sampling speed and high precision are built into the E5\_C series, Omron's 2-PID control is a key factor behind the advantage it offers over standard controllers. Using a powerful algorithm, it makes all the difference to control stability and thus the quality of your products.

# High-contrast display

#### Easy-to-read White Characters with Large Display Size\*1

Big white characters on a black background achieve superior visibility. You can quickly and reliably check the PV from wide viewing angles, with natural light or in the subdued lighting conditions.

Character Height* (White PV)
E5GC: 10.5 mm
E5CC: 15.2 mm
E5EC : 18 mm
E5AC: 25 mm





The display remains easy to read even from wide viewing angles.

Shift Key to Reduce the Setting Work

For example, to set 100°C, it was previously necessary to

increment one degree at a time with a key, but with the

shift key ( << PF ), you can instantly change the digit. This

#### Save space!

The compact and space-saving design of the new E5\_C controller generation requires less panel depth (60 mm)<sup>\*2</sup>, allowing quick snap-mounting and easy installation even under very cramped conditions. \*<sup>2</sup> Excluding E5GC/E5DC/E5CC-U

Thanks to the IP66 protection\*<sup>3</sup> of the front cover, the E5\_C can withstand humid environments and also be cleaned with non-aggressive fluids. \*<sup>3</sup> Excluding E5DC/E5CC-U



**Required to Enter Values** 

simplifies numeric entry at worksite.



Just press the shift key to move the digit.

# Easy to connect, set-up and operate

#### USB Bus Power Eliminates the Need for a Power Supply

Even if you don't connect a power supply to the Controller, power is supplied from the computer.



#### Easy connections to a PLC with programless communications.





step3

#### Communications start.

**More Convenient** Operations





in the Temperature Controllers.

The parameters can be copied from the master Temperature Controller to slave Temperature Controllers.

#### Advantages

- The amount of work to set up the system is greatly reduced. PLC programming and memory are not required
- for communications.
- Communications even with multiple Temperature Controllers are automatically executed by the Temperature Controllers.
- Interface converters are not required, which reduces costs. Number of connected Digital Temperature Controllers: 32 max.
- (Up to 16 for the FX Series)



Master Temperature Controller can share RUN/STOP commands and set points with slave Temperature Controllers. Slope and offsets can be set for the set point.

# Easy-to-read Display in the Compact Body (48 x 24 mm) with a Stylish Panel-mounting Design

# Easy-to-read: White Characters and Dual Displays with the Largest Character Height in the Industry.\*1

The 48 x 24 mm size compact body inherits the high-visibility, big white characters from the E5\_C series.


With the dual, side-by-side displays (PV and green SV), there is no need to switch the display.

\*1 According to OMRON investigation, March 2014.



#### Controllers with Screwless Clamp Terminal Blocks for Easy Wiring

In addition to the models with screw terminal blocks, models with screwless clamp terminal blocks are also available. Easy wiring by inserting wires simplifies the wiring work.



#### Group mounting Horizontally or Vertically further downsizes machines

The E5GC allows group mounting not only horizontally, but also vertically. This helps reduce machine size even further when more than one Temperature Controller is used.\*<sup>2</sup>

- \*2 The ambient operating temperature must not exceed given below. Horizontal group mounting: 55°C Vertical group mounting of two Temperature Controllers: 45°C
- Vertical group mounting of three or more Temperature Controllers: 40°C \*3 Use Temperature Controllers with Screwless Clamp Terminal Blocks for vertical group mounting.






Removable Terminal Block for Easy Mounting and Replacement.



Removing from the Terminal Block The image is for illustration purpose only. \* Hooks must be pressed to remove from the terminal block.

Reduce Confirmation Work with Front-panel Display and Front-panel Key Settings

In-panel Temperature Controller



# Unique performance with simplicity...

#### ... and more control functionality

With key features like simplicity in operation, Omron's patented PID control, 50ms sampling period and the ability to handle multi-functional input and output types, the E5\_C sets a new standard in fast and precise temperature regulation. It has all the familiar functionality available from existing Omron temperature controllers to cover virtually any general-purpose demand. And naturally, the versatile E5\_C series is available with input/output combinations to perfectly match all of your requirements.






#### Extended inputs & outputs

- Remote SP input<sup>\*1</sup>
- Transfer output<sup>\*1</sup> (voltage 1-5 V output) added
- Event input\*2
- Auxiliary output
- \*1 Excluding E5GC/E5DC/E5CC-U
- \*2 Excluding E5CC-U

#### New feature

- Program-less communication
- Position-proportional control\*3 \*3 Only for E5EC/E5AC

.....



### **Global availability, support and network**

# Providing you with the support you need to operate globally


Whether you want to take your existing products into new industrial sectors, or whether you want to expand your business into entirely new geographical markets, Omron can help. We aim to offer the same level of support globally, without forgetting local needs.

#### We have production facilities on every continent.

Our smart communications network and seamless global support means we can provide you with parts and technical support wherever you sell your machines. And all of our components comply with major international standards, to ensure problem-free integration. It's all there for you.

#### Facts and figures

- Over 35,000 employees
- Almost 200 locations
- Presence in every continent
- Knowledge-sharing through our global infrastructure
- Local R&D facilities synchronised to local needs
- Local factories to ensure quick response
- Global pricing terms
- Global support



# E5GC Model list (Models 0,1 or 2 auxiliary outputs)

\*<sup>2</sup> Auxiliary outputs are not possible for these models.

# E5CC model list (all models 3 auxiliary outputs)

Output         Option No.*         Order code AC100-240V         Order code AC/DC24V           001         ESCC-RX3A5M-000         ESCC-RX3A5M-001           0ut 1: Relay 0ut 2: non         003         ESCC-RX3A5M-003         ESCC-RX3D5M-003           0ut 2: non         005         ESCC-RX3A5M-005         ESCC-RX3D5M-006           0ut 2: non         006         ESCC-RX3A5M-007         ESCC-RX3D5M-007           0ut 2: non         001         ESCC-RX3A5M-007         ESCC-RX3A5M-007           0ut 1: Voltage (pulse)         001         ESCC-RX3A5M-001         ESCC-0X3A5M-001           0ut 2: non         001         ESCC-RX3A5M-003         ESCC-0X3A5M-007           0ut 1: Voltage (pulse)         003         ESCC-0X3A5M-003         ESCC-0X3A5M-007           0ut 2: non         006         ESCC-0X3A5M-007         ESCC-0X3A5M-007           0ut 1: Voltage (pulse)         003         ESCC-0X3A5M-007				
AC100-240V         ACC/DC24V           Out 1: Relay         001         ESCC-RX3A5M-000         ESCC-RX3D5M-001           Out 2: non         005         ESCC-RX3A5M-005         ESCC-RX3D5M-005           Out 2: non         006         ESCC-RX3A5M-006         ESCC-RX3D5M-006           Out 2: non         006         ESCC-RX3A5M-005         ESCC-RX3D5M-006           Out 2: non         006         ESCC-RX3A5M-006         ESCC-RX3D5M-006           Out 1: Voltage (pulse)         001         ESCC-RX3A5M-003         ESCC-RX3D5M-007           Out 1: Voltage (pulse)         003         ESCC-0X3A5M-003         ESCC-0X3D5M-003           Out 2: non         006         ESCC-RX3A5M-005         ESCC-0X3D5M-003           Out 2: non         006         ESCC-0X3A5M-006         ESCC-0X3D5M-003           Out 2: non         006         ESCC-0X3A5M-006         ESCC-0X3D5M-007           Out 1: Voltage (pulse)         001         ESCC-0X3A5M-006         ESCC-0X3D5M-007           Out 1: Voltage (pulse)         001         ESCC-0X3A5M-006         ESCC-0X3D5M-007           Out 1: Voltage (pulse)         001         ESCC-0X3A5M-006         ESCC-0X3D5M-006           Out 1: Voltage (pulse)         001         ESCC-0X3A5M-006         ESCC-0X3D5M-007 <td< th=""><th>Output</th><th>Ontion No *</th><th>Order code</th><th>Order code</th></td<>	Output	Ontion No *	Order code	Order code
Out 1: Relay         OO1         ESCC-RX3A5M-001         ESCC-RX3D5M-003           Out 2: non         OO5         ESCC-RX3A5M-005         ESCC-RX3D5M-005           Out 2: non         OO6         ESCC-RX3A5M-007         ESCC-RX3D5M-007           Out 2: non         OO1         ESCC-RX3A5M-000         ESCC-RX3A5M-007           Out 2: non         OO1         ESCC-RX3A5M-001         ESCC-RX3A5M-007           Out 1: Voltage (pulse)         OO3         ESCC-QX3A5M-003         ESCC-QX3D5M-003           Out 2: non         OO5         ESCC-QX3A5M-006         ESCC-QX3D5M-006           Out 2: non         OO5         ESCC-QX3A5M-006         ESCC-QX3D5M-006           Out 2: non         OO6         ESCC-QX3A5M-006         ESCC-QX3D5M-006           Out 2: non         OO6         ESCC-QX3A5M-006         ESCC-QX3D5M-006           Out 2: voltage (pulse)         OO1         ESCC-QX3A5M-007         ESCC-QX3D5M-006           Out 1: voltage (pulse)         OO1         ESCC-QX3A5M-006         ESCC-QX3D5M-006           Out 2: voltage (pulse)         OO3         ESCC-QX3A5M-005         ESCC-QX3D5M-006           Out 1: voltage (pulse)         OO4         ESCC-QX3A5M-006         ESCC-QX3D5M-006           Out 1: linear current         OO4         ESCC-QX3A5M-006	Culput	option not	AC100-240V	AC/DC24V
Out 1: Relay Out 2: non         O03         ESCC-RX3A5M-003         ESCC-RX3D5M-005           006         ESCC-RX3A5M-006         ESCC-RX3D5M-006         ESCC-RX3D5M-006           006         ESCC-RX3A5M-007         ESCC-RX3D5M-000         ESCC-RX3D5M-000           001         ESCC-RX3A5M-000         ESCC-RX3D5M-000         ESCC-RX3D5M-000           001         ESCC-RX3A5M-000         ESCC-RX3D5M-000         ESCC-RX3D5M-000           001         ESCC-RX3A5M-000         ESCC-RX3D5M-000         ESCC-RX3D5M-000           001         ESCC-RX3A5M-000         ESCC-0X3D5M-003         ESCC-0X3D5M-003           001         ESCC-QX3A5M-005         ESCC-QX3D5M-006         ESCC-QX3D5M-006           001         ESCC-QX3A5M-007         ESCC-QX3D5M-006         ESCC-QX3D5M-007           001         ESCC-QX3A5M-007         ESCC-QX3D5M-006         ESCC-QX3D5M-007           001         ESCC-QX3A5M-007         ESCC-QX3D5M-003         ESCC-QX3D5M-003           001         ESCC-QX3A5M-003         ESCC-QX3D5M-003         ESCC-QX3D5M-003           001         ESCC-QX3A5M-003         ESCC-QX3D5M-003         ESCC-QX3D5M-003           001         ESCC-QX3A5M-003         ESCC-QX3D5M-003         ESCC-QX3D5M-003           001         ESCC-QX3A5M-004         ESCC-QX3D5M-004			E5CC-RX3A5M-000	E5CC-RX3D5M-000
Out 2: non         Out         ESC: RX35M-005         ESC: RX35M-006           00t 2: non         006         ESC: RX35M-006         ESC: RX35M-007           00t 1: Voltage (pulse)         001         ESC: CX35M-001         ESC: OX35M-003           00t 2: non         005         ESC: OX35M-003         ESC: OX35M-003           0ut 1: Voltage (pulse)         003         ESC: OX35M-006         ESC: OX35M-003           0ut 2: non         006         ESC: OX35M-003         ESC: OX35M-003           0ut 2: non         006         ESC: OX35M-006         ESC: OX35M-003           0ut 1: Voltage (pulse)         006         ESC: OX35M-007         ESC: OX35M-003           0ut 1: Voltage (pulse)         001         ESC: OX35M-003         ESC: OX35M-003           0ut 1: Voltage (pulse)         003         ESC: OX35M-003         ESC: OX35M-003           0ut 1: Voltage (pulse)         003         ESC: OX35M-003         ESC: OX35M-003           0ut 1: Voltage (pulse)         003         ESC: OX35M-003         ESC: OX35M-003           0ut 1: Voltage (pulse)         003         ESC: OX35M-003         ESC: OX35M-003           0ut 1: Voltage (pulse)         006         ESC: CX35M-004         ESC: CX35M-005           0ut 1: Linear current         004         ESC: CX			E5CC-RX3A5M-001	E5CC-RX3D5M-001
Out 1: Voltage (pulse)         OOG         ESCC-0X3ASM-006         ESCC-0X3DSM-006           001         ESCC-0X3ASM-000         ESCC-0X3DSM-000           0ut 1: Voltage (pulse)         O03         ESCC-0X3ASM-003         ESCC-0X3DSM-003           0ut 2: non         O06         ESCC-0X3ASM-005         ESCC-0X3DSM-003           0ut 2: non         O06         ESCC-0X3ASM-005         ESCC-0X3DSM-003           0ut 2: non         O06         ESCC-0X3ASM-005         ESCC-0X3DSM-007           0ut 1: Voltage (pulse)         O06         ESCC-0X3ASM-006         ESCC-0X3DSM-007           0ut 1: Voltage (pulse)         O06         ESCC-0X3ASM-005         ESCC-0X3DSM-007           0ut 1: Voltage (pulse)         O01         ESCC-003ASM-006         ESCC-003DSM-007           0ut 2: Voltage (pulse)         O01         ESCC-003ASM-003         ESCC-003DSM-003           0ut 1: Linear current Out 2: non         O04         ESCC-003ASM-006         ESCC-003DSM-007           0ut 1: Linear current Out 2: non         O04         ESCC-003ASM-006         ESCC-0X3DSM-006           005         ESCC-0X3ASM-006         ESCC-0X3DSM-007         ESCC-0X3DSM-007           004         ESCC-0X3ASM-006         ESCC-0X3DSM-007           005         ESCC-0X3ASM-006         ESCC-0X3DSM-007 <td>Out 1: Relay</td> <td></td> <td>E5CC-RX3A5M-003</td> <td>E5CC-RX3D5M-003</td>	Out 1: Relay		E5CC-RX3A5M-003	E5CC-RX3D5M-003
O07         ESCC-RX3A5M-007         ESCC-RX3DSM-007           Out 1: Voltage (pulse)         O01         ESCC-0X3A5M-001         ESCC-0X3DSM-003           Out 1: Voltage (pulse)         O03         ESCC-0X3A5M-003         ESCC-0X3DSM-003           Out 2: non         O06         ESCC-0X3A5M-006         ESCC-0X3DSM-006           Out 2: non         O06         ESCC-0X3A5M-007         ESCC-0X3DSM-006           Out 1: Voltage (pulse)         O07         ESCC-0X3A5M-007         ESCC-0X3DSM-007           Out 1: Voltage (pulse)         O01         ESCC-0X3A5M-007         ESCC-0X3DSM-007           Out 1: Voltage (pulse)         O01         ESCC-003A5M-007         ESCC-003DSM-000           Out 1: Voltage (pulse)         O01         ESCC-003A5M-005         ESCC-003DSM-007           Out 1: Voltage (pulse)         O03         ESCC-003A5M-005         ESCC-003DSM-003           Out 1: Voltage (pulse)         O03         ESCC-003A5M-005         ESCC-003DSM-005           Out 1: Linear current         O06         ESCC-003A5M-006         ESCC-003DSM-007           Out 1: Linear current         O04         ESCC-CX3A5M-006         ESCC-CX3DSM-006           Out 1: Linear current         O06         ESCC-C03A5M-006         ESCC-C03DSM-007           Out 1: Linear current         O01 <td>Out 2: non</td> <td>&gt; 005</td> <td>E5CC-RX3A5M-005</td> <td>E5CC-RX3D5M-005</td>	Out 2: non	> 005	E5CC-RX3A5M-005	E5CC-RX3D5M-005
Out         ESCC-0X3ASM-000         ESCC-0X3DSM-000           Out 1: Voltage (pulse)         003         ESCC-0X3ASM-003         ESCC-0X3DSM-003           Out 2: non         005         ESCC-0X3ASM-006         ESCC-0X3DSM-005           Out 2: non         006         ESCC-0X3ASM-007         ESCC-0X3DSM-006           Out 1: Voltage (pulse)         001         ESCC-003ASM-000         ESCC-003DSM-006           Out 1: Voltage (pulse)         001         ESCC-003ASM-001         ESCC-003DSM-007           Out 1: Voltage (pulse)         001         ESCC-003ASM-001         ESCC-003DSM-007           Out 1: Voltage (pulse)         003         ESCC-003ASM-005         ESCC-003DSM-006           Out 2: Voltage (pulse)         006         ESCC-003ASM-005         ESCC-003DSM-006           Out 1: Linear current out 2: non         004         ESCC-CX3ASM-004         ESCC-CX3DSM-004           Out 1: Linear current out 2: non         006         ESCC-CX3ASM-006         ESCC-CX3DSM-007           Out 1: Linear current out 2: non         001         ESCC-C03ASM-001         ESCC-CX3DSM-007           Out 1: Linear current out 2: non         001         ESCC-C03ASM-001         ESCC-CX3DSM-007           Out 2: Voltage (pulse)         003         ESCC-C03ASM-001         ESCC-CX3DSM-007           Out		> 006	E5CC-RX3A5M-006	E5CC-RX3D5M-006
Out 1: Voltage (pulse)         OO1         ESCC-0X3A5M-OO1         ESCC-0X3D5M-OO3           Out 2: non         005         ESCC-0X3A5M-005         ESCC-0X3D5M-005           Out 2: non         006         ESCC-0X3A5M-006         ESCC-0X3D5M-006           Out 1: Voltage (pulse)         006         ESCC-0X3A5M-007         ESCC-0X3D5M-007           Out 1: Voltage (pulse)         001         ESCC-0X3A5M-007         ESCC-0X3D5M-007           Out 1: Voltage (pulse)         001         ESCC-0X3A5M-007         ESCC-0X3D5M-007           Out 1: Voltage (pulse)         003         ESCC-0X3A5M-007         ESCC-0X3D5M-007           Out 2: Voltage (pulse)         003         ESCC-003A5M-005         ESCC-0X3D5M-003           Out 1: Voltage (pulse)         005         ESCC-003A5M-005         ESCC-003D5M-005           Out 2: Voltage (pulse)         006         ESCC-003A5M-006         ESCC-003D5M-007           Out 1: Linear current Out 2: non         004         ESCC-CX3A5M-006         ESCC-CX3D5M-006           Out 1: Linear current Out 2: Voltage (pulse)         001         ESCC-003A5M-001         ESCC-003D5M-007           Out 1: Linear current Ou3         003         ESCC-C03A5M-001         ESCC-C03D5M-006           Out 2: Voltage (pulse)         001         ESCC-C03A5M-003         ESCC-C03D5M-001		> 007	E5CC-RX3A5M-007	E5CC-RX3D5M-007
Out 1: Voltage (pulse)         OO3         E5CC-0X3A5M-003         E5CC-0X3D5M-003           Out 2: non         OO6         E5CC-0X3A5M-005         E5CC-0X3D5M-005           Out 1: Voltage (pulse)         OO1         E5CC-0X3A5M-007         E5CC-0X3D5M-007           Out 1: Voltage (pulse)         OO1         E5CC-0X3A5M-003         E5CC-0X3D5M-000           Out 1: Voltage (pulse)         OO1         E5CC-0X3A5M-003         E5CC-0X3D5M-007           Out 1: Voltage (pulse)         OO3         E5CC-0X3A5M-003         E5CC-0X3D5M-003           Out 2: voltage (pulse)         OO3         E5CC-0X3A5M-003         E5CC-0X3D5M-003           Out 2: voltage (pulse)         OO3         E5CC-0X3A5M-003         E5CC-0X3D5M-003           Out 1: Linear current         OO6         E5CC-0X3A5M-006         E5CC-0X3D5M-006           Out 1: Linear current         OO4         E5CC-CX3A5M-004         E5CC-CX3D5M-005           Out 1: Linear current         OO6         E5CC-CX3A5M-007         E5CC-CX3D5M-006           Out 1: Linear current         OO1         E5CC-C03A5M-007         E5CC-C03D5M-007           Out 1: Linear current         OO3         E5CC-C03A5M-007         E5CC-C03D5M-007           Out 1: Linear current         OO3         E5CC-C03A5M-007         E5CC-C03D5M-007           <			> E5CC-QX3A5M-000	E5CC-QX3D5M-000
Out 2: non         OO5         ESCC-0X3A5M-005         ESCC-0X3A5M-006           0005         ESCC-0X3A5M-006         ESCC-0X3A5M-006         ESCC-0X3D5M-006           0001         ESCC-0X3A5M-000         ESCC-0X3D5M-000         ESCC-0X3D5M-000           001         ESCC-0X3A5M-001         ESCC-0X3D5M-001         ESCC-0X3D5M-001           001         ESCC-0X3A5M-003         ESCC-0X3D5M-003         ESCC-0X3D5M-003           001         ESCC-0X3A5M-005         ESCC-0X3D5M-003         ESCC-0X3D5M-003           001         ESCC-0X3A5M-005         ESCC-0X3D5M-003         ESCC-0X3D5M-003           001         ESCC-0X3A5M-005         ESCC-0X3D5M-003         ESCC-0X3D5M-003           001         ESCC-0X3A5M-005         ESCC-0X3D5M-006         ESCC-0X3D5M-005           002         006         ESCC-0X3A5M-007         ESCC-0X3D5M-006           001         ESCC-CX3A5M-000         ESCC-CX3D5M-006         ESCC-CX3D5M-006           002         004         ESCC-CX3A5M-007         ESCC-0X3D5M-007           004         ESCC-CX3A5M-006         ESCC-CX3D5M-006         ESCC-CX3D5M-007           005         ESCC-CX3A5M-007         ESCC-CX3D5M-007         ESCC-CX3D5M-007           004         ESCC-CX3A5M-000         ESCC-CX3D5M-001         ESCC-CX3D5M-001 </td <td></td> <td>&gt; 001</td> <td>E5CC-QX3A5M-001</td> <td>E5CC-QX3D5M-001</td>		> 001	E5CC-QX3A5M-001	E5CC-QX3D5M-001
Out 1: Voltage (pulse)         O06         E5CC-0X3A5M-006         E5CC-0X3D5M-006           Out 1: Voltage (pulse)         O01         E5CC-0X3A5M-000         E5CC-0X3D5M-000           Out 2: Voltage (pulse)         O03         E5CC-0X3A5M-003         E5CC-0X3D5M-001           Out 2: Voltage (pulse)         O03         E5CC-0X3A5M-003         E5CC-0X3D5M-003           Out 2: Voltage (pulse)         O05         E5CC-0X3A5M-005         E5CC-003A5M-005           Out 2: Voltage (pulse)         O066         E5CC-0X3A5M-006         E5CC-003A5M-005           Out 2: Voltage (pulse)         O066         E5CC-0X3A5M-006         E5CC-003A5M-005           Out 2: Voltage (pulse)         O066         E5CC-003A5M-006         E5CC-003A5M-005           Out 1: Linear current         O06         E5CC-CX3A5M-007         E5CC-CX3D5M-007           Out 1: Linear current         O06         E5CC-CX3A5M-005         E5CC-CX3D5M-005           Out 1: Linear current         O06         E5CC-CX3A5M-006         E5CC-CX3D5M-007           Out 1: Linear current         O01         E5CC-C03A5M-001         E5CC-C03D5M-001           Out 1: Linear current         O03         E5CC-C03A5M-003         E5CC-C03D5M-003           Out 1: Linear current         O03         E5CC-C03A5M-003         E5CC-C03D5M-003	Out 1: Voltage (pulse)	> 003	E5CC-QX3A5M-003	E5CC-QX3D5M-003
OO7         E5CC-0X3A5M-007         E5CC-0X3D5M-007           Out 1: Voltage (pulse)         O01         E5CC-003A5M-000         E5CC-003D5M-000           Out 2: Voltage (pulse)         O03         E5CC-003A5M-003         E5CC-003D5M-003           (pulse)         O05         E5CC-003A5M-005         E5CC-003D5M-005           006         E5CC-003A5M-006         E5CC-003D5M-005           007         E5CC-003A5M-006         E5CC-003D5M-005           006         E5CC-003A5M-007         E5CC-003D5M-006           007         E5CC-003A5M-006         E5CC-003D5M-007           006         E5CC-003A5M-007         E5CC-003D5M-007           007         E5CC-003A5M-007         E5CC-003D5M-007           007         E5CC-003A5M-007         E5CC-003D5M-007           008         E5CC-CX3A5M-004         E5CC-CX3D5M-004           0095         E5CC-CX3A5M-005         E5CC-CX3D5M-005           001         E5CC-CX3A5M-006         E5CC-CX3D5M-007           001         E5CC-C03A5M-001         E5CC-C03D5M-001           001         E5CC-C03A5M-003         E5CC-C03D5M-003           001         E5CC-C03A5M-003         E5CC-C03D5M-003           001         E5CC-C03A5M-003         E5CC-C03D5M-003           001	Out 2: non	> 005	E5CC-QX3A5M-005	E5CC-QX3D5M-005
Out 1: Voltage (pulse)         O01         E5CC-003A5M-000         E5CC-003D5M-001           Out 2: Voltage (pulse)         003         E5CC-003A5M-003         E5CC-003D5M-003           Out 2: Voltage (pulse)         005         E5CC-003A5M-005         E5CC-003D5M-005           Out 006         E5CC-003A5M-006         E5CC-003D5M-006         E5CC-003D5M-006           Out 1: Linear current Out 2: non         004         E5CC-CX3A5M-004         E5CC-CX3D5M-005           Out 1: Linear current Out 2: non         006         E5CC-C03A5M-007         E5CC-CX3D5M-006           Out 1: Linear current Out 2: non         006         E5CC-C03A5M-007         E5CC-CX3D5M-006           Out 1: Linear current Out 2: non         001         E5CC-C03A5M-007         E5CC-CX3D5M-006           Out 1: Linear current Out 2: non         001         E5CC-C03A5M-007         E5CC-C03D5M-007           Out 1: Linear Current Out 2: non         001         E5CC-C03A5M-007         E5CC-C03D5M-006           Out 1: Linear Current Out 2: voltage         001         E5CC-C03A5M-001         E5CC-C03D5M-001           Out 2: Voltage         005         E5CC-C03A5M-003         E5CC-C03D5M-003         E5CC-C03D5M-005           (pulse)         006         E5CC-C03A5M-005         E5CC-C03D5M-005         E5CC-C03D5M-005         E5CC-C03D5M-005         <		> 006	E5CC-QX3A5M-006	E5CC-QX3D5M-006
Out 1: Voltage (pulse)         O01         E5CC-Q03A5M-001         E5CC-Q03D5M-003           Out 2: Voltage (pulse)         003         E5CC-Q03A5M-003         E5CC-Q03D5M-003           Out 2: Voltage (pulse)         005         E5CC-Q03A5M-005         E5CC-Q03D5M-005           006         E5CC-Q03A5M-006         E5CC-Q03D5M-006         E5CC-Q03D5M-006           007         E5CC-Q03A5M-007         E5CC-Q03D5M-007           004         E5CC-CX3A5M-004         E5CC-CX3D5M-004           005         E5CC-CX3A5M-004         E5CC-CX3D5M-005           004         E5CC-CX3A5M-004         E5CC-CX3D5M-006           005         E5CC-CX3A5M-006         E5CC-CX3D5M-006           004         E5CC-CX3A5M-006         E5CC-CX3D5M-005           006         E5CC-CX3A5M-006         E5CC-CX3D5M-006           007         E5CC-CX3A5M-006         E5CC-CX3D5M-006           006         E5CC-CX3A5M-007         E5CC-CX3D5M-007           007         E5CC-C03A5M-000         E5CC-C03D5M-001           001         E5CC-C03A5M-001         E5CC-C03D5M-001           001         E5CC-C03A5M-003         E5CC-C03D5M-003           001         E5CC-C03A5M-003         E5CC-C03D5M-003           001         E5CC-C03A5M-005         E5CC-C03D5M-00		> 007	E5CC-QX3A5M-007	E5CC-QX3D5M-007
Out 1: Voltage (pulse)         OO3         E5CC-Q03A5M-003         E5CC-Q03D5M-003           Out 2: Voltage (pulse)         OO5         E5CC-Q03A5M-005         E5CC-Q03D5M-005           OO6         E5CC-Q03A5M-006         E5CC-Q03D5M-006           OO7         E5CC-Q03A5M-007         E5CC-Q03D5M-007           OUt 1: Linear current Out 1: Linear current Out 2: non         OO4         E5CC-CX3A5M-004         E5CC-CX3D5M-004           OO6         E5CC-CX3A5M-005         E5CC-CX3D5M-006         E5CC-CX3D5M-007           Out 1: Linear current Out 2: non         OO6         E5CC-CX3A5M-006         E5CC-CX3D5M-006           Out 1: Linear current         OO1         E5CC-CQ3A5M-007         E5CC-CQ3D5M-007           Out 1: Linear current         OO1         E5CC-CQ3A5M-000         E5CC-CQ3D5M-001           Out 1: Linear current         OO3         E5CC-CQ3A5M-003         E5CC-CQ3D5M-003           Out 2: Voltage (pulse)         OO6         E5CC-CQ3A5M-003         E5CC-CQ3D5M-003			E5CC-QQ3A5M-000	E5CC-QQ3D5M-000
Out 2: Voltage (pulse)         OOS         ESCC 003ASM 003         ESCC 003DSM 003           006         ESCC-003ASM-006         ESCC-003DSM-006         ESCC-003DSM-006           007         ESCC-003ASM-007         ESCC-003DSM-007           001         ESCC-CX3ASM-004         ESCC-CX3DSM-004           005         ESCC-CX3ASM-006         ESCC-CX3DSM-006           001         ESCC-CX3ASM-006         ESCC-CX3DSM-007           001         ESCC-C03ASM-007         ESCC-C03DSM-007           001         ESCC-C03ASM-007         ESCC-C03DSM-007           001         ESCC-C03ASM-000         ESCC-C03DSM-000           001         ESCC-C03ASM-003         ESCC-C03DSM-003           002         003         ESCC-C03ASM-003         ESCC-C03DSM-003           001         ESCC-C03ASM-003         ESCC-C03DSM-003         ESCC-C03DSM-003           001         ESCC-C03ASM-003         ESCC-C03DSM-003         ESCC-C03DSM-003           001         ESCC-C03ASM-005         ESCC-C03DSM-005         ESCC-C03DSM-005           001         ESCC-C03ASM-003         ESCC-C03DSM-005         ESCC-C03DSM-005           001         ESCC-C03ASM-005         ESCC-C03DSM-005         ESCC-C03DSM-005           001         ESCC-C03ASM-005         ESCC-C03DSM-00		> 001	E5CC-QQ3A5M-001	E5CC-QQ3D5M-001
OUS         ESCC-003ASM-005         ESCC-003DSM-006           006         ESCC-003ASM-006         ESCC-003DSM-006           007         ESCC-003ASM-007         ESCC-003DSM-007           001         ESCC-CX3ASM-000         ESCC-CX3DSM-004           004         ESCC-CX3ASM-004         ESCC-CX3DSM-004           005         ESCC-CX3ASM-005         ESCC-CX3DSM-005           004         ESCC-CX3ASM-006         ESCC-CX3DSM-005           005         ESCC-CX3ASM-006         ESCC-CX3DSM-005           006         ESCC-CX3ASM-006         ESCC-CX3DSM-006           007         ESCC-CX3ASM-006         ESCC-CX3DSM-006           006         ESCC-CX3ASM-006         ESCC-CX3DSM-007           007         ESCC-CX3ASM-007         ESCC-CX3DSM-007           007         ESCC-CX3ASM-000         ESCC-CX3DSM-000           001         ESCC-CX3ASM-000         ESCC-CX3DSM-000           001         ESCC-C03ASM-001         ESCC-C03DSM-003           002         003         ESCC-C03ASM-003         ESCC-C03DSM-003           001         ESCC-C03ASM-005         ESCC-C03DSM-005         ESCC-C03DSM-005           001         ESCC-C03ASM-005         ESCC-C03DSM-005         ESCC-C03DSM-005           002         005 <td></td> <td>&gt; 003</td> <td>E5CC-QQ3A5M-003</td> <td>E5CC-QQ3D5M-003</td>		> 003	E5CC-QQ3A5M-003	E5CC-QQ3D5M-003
006         E5CC-QQ3A5M-006         E5CC-QQ3D5M-006           007         E5CC-QQ3A5M-007         E5CC-QQ3D5M-007           001         E5CC-CX3A5M-000         E5CC-CX3D5M-000           004         E5CC-CX3A5M-004         E5CC-CX3D5M-004           005         E5CC-CX3A5M-005         E5CC-CX3D5M-005           006         E5CC-CX3A5M-006         E5CC-CX3D5M-006           007         E5CC-CX3A5M-006         E5CC-CX3D5M-006           006         E5CC-CX3A5M-007         E5CC-CX3D5M-007           007         E5CC-CQ3A5M-007         E5CC-CX3D5M-007           007         E5CC-CQ3A5M-000         E5CC-CX3D5M-007           001         E5CC-CQ3A5M-000         E5CC-CQ3D5M-000           003         E5CC-CQ3A5M-003         E5CC-CQ3D5M-003           004         E5CC-CQ3A5M-005         E5CC-CQ3D5M-005           001         E5CC-CQ3A5M-003         E5CC-CQ3D5M-003           002         005         E5CC-CQ3A5M-005         E5CC-CQ3D5M-005           001         E5CC-CQ3A5M-005         E5CC-CQ3D5M-005         E5CC-CQ3D5M-005           001         E5CC-CQ3A5M-005         E5CC-CQ3D5M-005         E5CC-CQ3D5M-005         E5CC-CQ3D5M-005           001         E5CC-CQ3A5M-006         E5CC-CQ3D5M-005         E5CC-CQ3D5M-00	3	> 005	E5CC-QQ3A5M-005	5 E5CC-QQ3D5M-005
Out 1: Linear current         O04         E5CC-CX3A5M-004         E5CC-CX3D5M-004           Out 2: non         006         E5CC-CX3A5M-005         E5CC-CX3D5M-005           Out 1: Linear current         006         E5CC-CX3A5M-006         E5CC-CX3D5M-006           Out 1: Linear current         006         E5CC-CX3A5M-007         E5CC-CX3D5M-006           Out 1: Linear current         001         E5CC-C03A5M-000         E5CC-CQ3D5M-000           Out 1: Linear current         003         E5CC-C03A5M-003         E5CC-CQ3D5M-003           Out 2: Voltage         005         E5CC-C03A5M-005         E5CC-C03D5M-005           Out 2: Voltage         006         E5CC-C03A5M-006         E5CC-C03D5M-005           (pulse)         006         E5CC-C03A5M-005         E5CC-C03D5M-005	(p 4.00)	> 006	E5CC-QQ3A5M-006	5 E5CC-QQ3D5M-006
Out 1: Linear current         004         E5CC-CX3A5M-004         E5CC-CX3D5M-004           Out 2: non         005         E5CC-CX3A5M-005         E5CC-CX3D5M-005           O06         E5CC-CX3A5M-006         E5CC-CX3D5M-006           O07         E5CC-CX3A5M-007         E5CC-CX3D5M-007           Out 1: Linear         001         E5CC-C03A5M-001         E5CC-C03D5M-001           current         003         E5CC-C03A5M-003         E5CC-C03D5M-003           Out 2: Voltage         005         E5CC-C03A5M-005         E5CC-C03D5M-005           (pulse)         006         E5CC-C03A5M-006         E5CC-C03D5M-005		> 007	E5CC-QQ3A5M-007	E5CC-QQ3D5M-007
Out 1: Linear current         O05         E5CC-CX3A5M-005         E5CC-CX3D5M-005           Out 2: non         006         E5CC-CX3A5M-006         E5CC-CX3D5M-006           O07         E5CC-CX3A5M-007         E5CC-CX3D5M-007           Out 1: Linear         001         E5CC-C03A5M-001         E5CC-C03D5M-001           Out 1: Linear         001         E5CC-C03A5M-003         E5CC-C03D5M-001           Out 2: Voltage         005         E5CC-C03A5M-005         E5CC-C03D5M-003           Out 2: Voltage         006         E5CC-C03A5M-005         E5CC-C03D5M-005           (pulse)         006         E5CC-C03A5M-006         E5CC-C03D5M-005			E5CC-CX3A5M-000	E5CC-CX3D5M-000
Out 2: non         005         E5CC-CX3A5M-005         E5CC-CX3D5M-005           006         E5CC-CX3A5M-006         E5CC-CX3D5M-006           007         E5CC-CX3A5M-007         E5CC-CX3D5M-007           001         E5CC-C03A5M-000         E5CC-C03D5M-000           001         E5CC-C03A5M-001         E5CC-C03D5M-001           current         003         E5CC-C03A5M-003         E5CC-C03D5M-003           0ut 2: Voltage         005         E5CC-C03A5M-005         E5CC-C03D5M-005           (pulse)         006         E5CC-C03A5M-006         E5CC-C03D5M-006	Out to Lincor overant	> 004	E5CC-CX3A5M-004	E5CC-CX3D5M-004
006         E5CC-CX3A5M-006         E5CC-CX3D5M-006           007         E5CC-CX3A5M-007         E5CC-CX3D5M-007           001         E5CC-C03A5M-000         E5CC-C03D5M-000           003         E5CC-C03A5M-003         E5CC-C03D5M-001           004 1: Linear         003         E5CC-C03A5M-003         E5CC-C03D5M-001           0ut 2: Voltage         005         E5CC-C03A5M-005         E5CC-C03D5M-005           (pulse)         006         E5CC-C03A5M-006         E5CC-C03D5M-006		> 005	E5CC-CX3A5M-005	E5CC-CX3D5M-005
Out 1: Linear         O01         E5CC-CQ3A5M-000         E5CC-CQ3D5M-000           current         003         E5CC-CQ3A5M-003         E5CC-CQ3D5M-001           Out 2: Voltage         005         E5CC-CQ3A5M-005         E5CC-CQ3D5M-005           (pulse)         006         E5CC-CQ3A5M-006         E5CC-CQ3D5M-006	out 2. non	> 006	E5CC-CX3A5M-006	E5CC-CX3D5M-006
Out 1: Linear current         O01         E5CC-CQ3A5M-001         E5CC-CQ3D5M-001           Out 2: Voltage (pulse)         O05         E5CC-CQ3A5M-005         E5CC-CQ3D5M-005           Out 2: Voltage         O06         E5CC-CQ3A5M-006         E5CC-CQ3D5M-006		> 007	E5CC-CX3A5M-007	E5CC-CX3D5M-007
Out :: Entern         O03         E5CC-CQ3A5M-003         E5CC-CQ3D5M-003           Out 2: Voltage         O05         E5CC-CQ3A5M-005         E5CC-CQ3D5M-005           (pulse)         O06         E5CC-CQ3A5M-006         E5CC-CQ3D5M-006			> E5CC-CQ3A5M-000	E5CC-CQ3D5M-000
Out 2: Voltage         O05         E5CC-CQ3A5M-005         E5CC-CQ3D5M-005           (pulse)         006         E5CC-CQ3A5M-006         E5CC-CQ3D5M-006	Out 1: Linear		E5CC-CQ3A5M-001	E5CC-CQ3D5M-001
(pulse) > 006 > E5CC-CQ3A5M-006 E5CC-CQ3D5M-006		> 003	E5CC-CQ3A5M-003	E5CC-CQ3D5M-003
		> 005	E5CC-CQ3A5M-005	E5CC-CQ3D5M-005
007 F5CC-C03A5M-007 F5CC-C03D5M-007	(pulse)	> 006		E5CC-CQ3D5M-006
		> 007	E5CC-CQ3A5M-007	E5CC-CQ3D5M-007

As well as these models, other models are available on request. Please contact the local sales office for special requests.

\* Option No.:

**001** Event Input 2, Heater Burnout SSR defect detection

**003** Communication 3-phase heater alarm **004** Event Input 2, Communication **005** Event Input 4 006

Event Input 2, Transfer output

007

Event Input 2, Remote SP

# E5EC/E5AC Model list (all models 4 auxiliary outputs)

and the second				
Output	Option No.*		Order code	Order code
output	Option No.	1000	AC100-240V	AC/DC24V
		<b></b>	E5 C-RX4A5M-000	E5 C-RX4D5M-000
Out 1: Relay	> 009	>	E5_C-RX4A5M-009	E5_C-RX4D5M-009
Out 2: non	→ 010	>	E5_C-RX4A5M-010	E5_C-RX4D5M-010
	-> 011	>	E5_C-RX4A5M-011	E5_C-RX4D5M-011
		>	E5_C-QX4A5M-000	E5_C-QX4D5M-000
Out 1: Voltage (pulse)	→ 009	>	E5_C-QX4A5M-009	E5_C-QX4D5M-009
Out 2: non	→ 010	>	E5_C-QX4A5M-010	E5_C-QX4D5M-010
	-> 011	>	E5_C-QX4A5M-011	E5_C-QX4D5M-011
		>	E5_C-RR4A5M-000	E5_C-RR4D5M-000
Out 1: Relay	→ 009	<b></b>	E5_C-RR4A5M-009	E5_C-RR4D5M-009
Out 2: Relay	→ 010	>	E5_C-RR4A5M-010	E5_C-RR4D5M-010
	→ 011	>	E5_C-RR4A5M-011	E5_C-RR4D5M-011
			E5_C-QQ4A5M-000	E5_C-QQ4D5M-000
Out 1: Voltage (pulse)	→ 009	>	E5_C-QQ4A5M-009	E5_C-QQ4D5M-009
Out 2: Voltage (pulse)	→ 010	>	E5_C-QQ4A5M-010	E5_C-QQ4D5M-010
(puise)	→ 011	>	E5_C-QQ4A5M-011	E5_C-QQ4D5M-011
			E5_C-QR4A5M-000	E5_C-QR4D5M-000
Out 1: Voltage (pulse)	→ 009	<b>→</b>	E5_C-QR4A5M-009	E5_C-QR4D5M-009
Out 2: Relay	→ 010	<b>→</b>	E5_C-QR4A5M-010	E5_C-QR4D5M-010
	→ 011	>	E5_C-QR4A5M-011	E5_C-QR4D5M-011
		>	E5_C-CX4A5M-000	E5_C-CX4D5M-000
Out to Linear suggest	→ 004	→	E5_C-CX4A5M-004	E5_C-CX4D5M-004
Out 1: Linear current Out 2: non	→ 005	>	E5_C-CX4A5M-005	E5_C-CX4D5M-005
<b>Out 2.</b> non	-> 013	>	E5_C-CX4A5M-013	E5_C-CX4D5M-013
	-> 014	>	E5_C-CX4A5M-014	E5_C-CX4D5M-014
		>	E5_C-CC4A5M-000	E5_C-CC4D5M-000
Out 1: Linear current	> 004	>	E5_C-CC4A5M-004	E5_C-CC4D5M-004
Out 1: Linear current	> 005	>	E5_C-CC4A5M-005	E5_C-CC4D5M-005
	→ 013	>	E5_C-CC4A5M-013	E5_C-CC4D5M-013
	→ 014	>	E5_C-CC4A5M-014	E5_C-CC4D5M-014
Out 1: Linear		>	E5_C-CQ4A5M-000	E5_C-CQ4D5M-000
current	→ 009	>	E5_C-CQ4A5M-009	E5_C-CQ4D5M-009
Out 2: Voltage	→ 010	>	E5_C-CQ4A5M-010	E5_C-CQ4D5M-010
(pulse)	→ 011	>	E5_C-CQ4A5M-011	E5_C-CQ4D5M-011
Out 1: Relay*		>	E5_C-PR4A5M-000	E5_C-PR4D5M-000
Out 2: Relay*	→ 004	>	E5_C-PR4A5M-004	E5_C-PR4D5M-004
out L. Reidy	-> 014	>	E5_C-PR4A5M-014	E5_C-PR4D5M-014

\* Position proportional control model

\* Option No.: 004 005 009 010 011 Event Input 4 Event Input 2, Event Input 2, Event Input 4, Event Input 6, Heater Burnout SSR Communication Communication Remote SP, 3-phase heater defect detection Heater Burnout SSR alarm defect detection, Transfer output 014 013 Event Input 6, Event Input 4, Remote SP, Transfer output Communication Remote SP, Transfer output

## E5CC-U model list (models 0, 1 or 2 auxiliary outputs)

Order of AC100		Order code AC/DC24V
> E	E5CC-RWOAUM-000*2	E5CC-RWODUM-000*2
> [	ESCC-RW1AUM-000	E5CC-RW1DUM-000
	ESCC-RW2AUM-000	E5CC-RW2DUM-000
> E	ESCC-QXOAUM-000*2	E5CC-QXODUM-000*2
	ESCC-QX1AUM-000	E5CC-QX1DUM-000
> E	ESCC-QX2AUM-000	E5CC-QX2DUM-000
> E	E5CC-CXOAUM-000*2	E5CC-CXODUM-000*2
	ESCC-CX1AUM-000	E5CC-CX1DUM-000
	ESCC-CX2AUM-000	E5CC-CX2DUM-000

## E5DC model list (models 0 or 2 auxiliary outputs)

Output	Option No.*1	Order code AC100-240V	Order code AC/DC24V
		> E5DC-RX2ASM-00	0 E5DC-RX2DSM-000
		E5DC-RX2AUM-00	0 E5DC-RX2DUM-000
	> 002	E5DC-RX2ASM-00	2 E5DC-RX2DSM-002
Out 1: Relay	002	E5DC-RX2AUM-00	2 E5DC-RX2DUM-002
	> 015	E5DC-RXOASM-01	5*2 E5DC-RX0DSM-015*2
	015	E5DC-RXOAUM-01	5*2 E5DC-RX0DUM-015*2
	→ 017	E5DC-RX2ASM-017	7 E5DC-RX2DSM-017
		E5DC-RX2AUM-01	7 E5DC-RX2DUM-017
		E5DC-QX2ASM-00	0 E5DC-QX2DSM-000
		E5DC-QX2AUM-00	0 E5DC-QX2DUM-000
	> 002	E5DC-QX2ASM-00	2 E5DC-QX2DSM-002
Out 1: Voltage (pulse)	→ 002	E5DC-QX2AUM-00	2 E5DC-QX2DUM-002
	> 015	E5DC-QXOASM-01	5*2 E5DC-QXODSM-015*2
		E5DC-QXOAUM-01	5*2 E5DC-QXODUM-015*2
	> 017	E5DC-QX2ASM-017	7 E5DC-QX2DSM-017
		E5DC-QX2AUM-01	7 E5DC-QX2DUM-017
		E5DC-CX2ASM-00	0 E5DC-CX2DSM-000
		E5DC-CX2AUM-00	0 E5DC-CX2DUM-000
	015	E5DC-CXOASM-015	5*2 E5DC-CX0DSM-015*2
Out 1: Liner cuurent	→ 015	E5DC-CXOAUM-01	5*2 E5DC-CX0DUM-015*2
	015	E5DC-CX2ASM-015	5 E5DC-CX2DSM-015
	> 015	E5DC-CX2AUM-01	5 E5DC-CX2DUM-015
	01/	E5DC-CX2ASM-016	E5DC-CX2DSM-016
	> 016	E5DC-CX2AUM-01	6 E5DC-CX2DUM-016

\*1 Option No.: OO2 Communication, Heater Burnout SSR defect detection
O15 Communication
O16 Event Input 1
Event Input 1
Heater Burnout SSR defect detection
O17

\*<sup>2</sup> Auxiliary outputs are not possible for these models.



#### High performance & simplicity

The next generation E5\_C temperature controller is setting a new global standard in terms of precision and user-friendly design. Best control performance, easy set-up and outstanding visibility of the white IP66 LCD display have been integrated into a space-saving housing with only 60 mm\* of depth. \* Excluding E5GC

- · Fast and precise regulation: 50ms sampling loop period time
- Easy to set up, and operate intuitively via CX-Thermo without power supply •
- Best contrast display using white LCD technology which is visible from a far distance and from any angle
- · Useful alarm and diagnosis functions for secure operation

#### **Specifications**

		E5GC	E5CC	E5EC	E5AC	
Power supply voltage		A in model number: 100 to 240 VAC, 5	0/60 Hz D in model number: 24 VAC,	50/60 Hz; 24 VDC		
Operating voltage range		85% to 110% of rated supply voltage				
Power consumption		5.9VA max. at 100 to 240 VAC, and 3.2VA max. at 24 VAC or 1.8W max. at 24 VDC	Models with option selection of 000: 5.2 VA max. at 100 to 240 VAC, and 3.1 VA max. at 24 VAC or1.6 W max. at 24 VDC All other models: 6.5 VA max. at 100 to 240 VAC, and 4.1 VA max. at 24 VAC or 2.3 W max. at 24 VDC	Models with option selection of 000: 6.6 VA max. at 100 to 240 VAC, and 4.1 VA max. at 24 VAC or 2.3 W max. at 24 VDC All other models: 8.3 VA max. at 100 to 240 VAC, and 5.5 VA max. at 24 VAC or 3.2 W max. at 24 VDC	Models with option selection of 000: 7.0 VA max. at 100 to 240 VAC, and 4.2 VA max. at 24 VAC or 2.4 W max. at 24 VDC All other models: 9.0 VA max. at 100 to 240 VAC, and 5.6 VA max. at 24 VAC or 3.4 W max. at 24 VDC	
Sensor input		<ul> <li>Temperature input Thermocouple: K, J, T, E, L, U, N, R, S, B, W, or PL II Platinum resistance thermometer : Pt100 or JPt100 Infrared temperature sensor (ES1B): 10 to 70°C, 60 to 120°C, 115 to 165°C, or 140 to 260°C</li> <li>Analog input Current input: 4 to 20 mA or 0 to 20 mA Voltage input: 1 to 5 V, 0 to 5 V, or 0 to 10 V</li> </ul>				
Input impedan	CB	Current input: 150 $\Omega$ max., Voltage inp	• • • •			
Control metho		ON/OFF control or 2-PID control (with a	`			
Indication accuracy (at the ambient temperature of 23°C)		Thermocouple:       (±0.3% of indication value or ±1°C, whichever is greater) ±1 digit max. <sup>11</sup> Platinum resistance thermometer:       (±0.2% of indication value or ±0.8°C, whichever is greater) ±1 digit max.         (±0.2% of indication value or ±0.8°C, whichever is greater) ±1 digit max.       Thermocouple:         (±0.2% of indication value or ±0.8°C, whichever is greater) ±1 digit max.       Platinum resistance thermometer:         (±0.2% of indication value or ±0.8°C, whichever is greater) ±1 digit max.       Analog input: ±0.2% FS ±1 digit max.         CT input: ±5% FS ±1 digit max.       CT input: ±5% FS ±1 digit max.         Potentiometer input: ±5% FS ±1 digit max.			whichever is greater) $\pm 1$ digit max.	
Auto-Tuning		Yes, 40%/100% MV output limit select	ion. When using Heat/Cool: Independen	t Heat & cool PID can be set by Auto-tur		
Self-Tuning		Yes	· · · ·	· · · · · · · · · · · · · · · · · · ·	-	
Control output	Relay output	SPST-NO, 250 VAC, 2 A (resistive load), electrical life; 100,000 operations, minimum applicable load: 5 V, 10 mA (reference value)	SPST-NO, 250 VAC, 3 A (resistive load), electrical life; 100,000 operations, minimum applicable load: 5 V, 10 mA (reference value)	SPST-NO, 250 VAC, 5 A (resistive load), electrical life; 100,000 operations, minimum applicable load: 5 V, 10 mA (reference value)		
Voltage output (for driving SSR)		Output voltage: 12 VDC $\pm$ 20% (PNP), n load current: 21 mA, with short-circuit		Output voltage: 12 VDC ±20% (PNP), r load current: 40 mA, with short-circuit (The maximum load current is 21 mA	protection circuit	
	Linear current output	4 to 20 mA DC/0 to 20 mA DC, load: 50	D0 $\Omega$ max., resolution: approx. 10,000			
Auxiliary output	Number of outputs	1 or 2 (depends on model)	3	4		
	Output specifications	SPST-NO relay outputs, 250 VAC, : 2 A (resistive load), Electrical life: 100,000 operations, Minimum applicable load: 10 mA at 5 V (reference value)	SPST-N0 relay outputs, 250 VAC, Models with 1 or 2 outputs: 3 A (resistive load), or Models with 3 outputs: 2 A (resistive load), Electrical life: 100,000 operations, Minimum applicable load: 10 mA at 5 V (reference value)	SPST-NO. relay outputs, 250 VAC, Models with 4 outputs: 2 A (resistive lo Electrical life: 100,000 operations, Minimum applicable load: 10 mA at 5	<i></i>	
Event input	Number of inputs	1 or 2 (depends on model)	2 or 4 (depends on model)	2, 4 or 6 (depends on model)		
		Contact input: ON: 1 k $\Omega$ max., OFF: 100	) kΩ min.			
	specifications	Non-contact input: ON: Residual voltag	e: 1.5 V max., OFF: Leakage current: 0.	.1 mA max.		
		Current flow: Approx. 7 mA per contact				
Setting methor	d	Digital setting using front panel keys				
Indication met	hod	11-segment digital display and individual indicators				
Multi SP		Up to eight set points (SP0 to SP7) can be saved and selected using the event inputs, key operations, or serial communications. <sup>2</sup>				
Other functions		Manual output, heating/cooling control, loop burnout alarm, SP ramp, other alarm functions, heater burnout (HB) alarm (including SSR failure (HS) alarm), 40% AT, 100% AT, WV limiter, input digital filter, self tuning, robust tuning, PV input shift, run/stop, protection functions, extraction of square root, MV change rate limit, logic operations, temperature status display, simple programming, moving average of input value, display brightness setting, simple transfer output, and work bit message <sup>-3</sup>				
Ambient operating temperature		-10 to 55°C (with no condensation or icing), for 3-year warranty: -10 to 50°C with standard mounting (with no condensation or icing)				
Ambient operating humidity		25% to 85%				
Storage temperature		-25 to 65°C (with no condensation or icing)				
Degree of protection		Front panel: IP66, Rear case: IP20, Terminals: IP00				
Input sampling period		50 ms				
Size in mm (HxWxD)		24×48×90 (Models with Screw Terminal Blocks)/ 24×48×93(Models with Screwless Clamp Terminal Blocks)	48×48×64	48×96×64	96×96×64	

Note: \*1. The indication accuracy of K thermocouples in the -200 to 1,300°C range, T and N thermocouples at a temperature of -100°C max., and U and L thermocouples at any temperatures is ±2°C ±1 digit max. The indication accuracy of the B thermocouple at a temperature of 400°C max. is not specified. The indication accuracy of B thermocouples at a temperature of 400 to 800°C is ±3°C max. The indication accuracy of the R and S thermocouples at a temperature of 200°C max. is ±3°C ±1 digit max. The indication accuracy of W thermocouples at a temperature of 200°C max. is ±3°C ±1 digit max. The indication accuracy of W thermocouples is thermocouples at a temperature of 200°C max. is ±3°C ±1 digit max. The indication accuracy of W thermocouples is thermocouples at a temperature of 200°C max. is ±3°C ±1 digit max. The indication accuracy of W thermocouples is thermocouples at a temperature of 200°C max. is ±3°C ±1 digit max. The indication accuracy of W thermocouples is thermocouples at a temperature of 200°C max. is ±3°C ±1 digit max. The indication accuracy of W thermocouples is thermocouples at a temperature of 200°C max. is ±3°C ±1 digit max. The indication accuracy of W thermocouples is the max of the R and S thermocouples at a temperature of 200°C max. is ±3°C ±1 digit max. The indication accuracy of W thermocouples is the max of the R and S thermocouples at a temperature of 200°C max. is ±3°C ±1 digit max. The indication accuracy of W thermocouples is the max of the R and S thermocouples at a temperature of 200°C max. is ±3°C ±1 digit max. The indication accuracy of W thermocouples at a temperature of 200°C max. is ±3°C ±1 digit max. The indication accuracy of W termocouples is the max of the R and S temperature of 200°C max. is ±3°C ±1 digit max of the R and S temperature of 200°C max of the R and S temperature of 200°C max of the R and S temperature of 200°C max of the R and S temperature of 200°C max of the R and S temperature of 200°C max of the R and S temperature of 200°C max of the R and S temperature of (±0.3% of PV or ±3°C, whichever is greater) ±1 digit max. The indication accuracy of PL II thermocouples is (±0.3% of PV or ±2°C, whichever is greater) ±1 digit max.

\*2. Only four set points are selectable for event inputs. \*3. Simple transfer output, and work bit message are only for E5GC.

E5\_C

# 280

#### High performance & DIN-Track Mounting

The next generation E5\_C temperature controller is setting a new global standard in terms of precision and user-friendly design. Best control performance, easy set-up and outstanding visibility of the white LCD display have been integrated into a space-saving housing.


- · Fast and precise regulation: 50ms sampling loop period time
- Easy to set up, and operate intuitively via CX-Thermo without power supply •
- Removable terminal block for easy mounting and replacement.\* •
- Useful alarm and diagnosis functions for secure operation •

\* Only for E5DC

#### **Specifications**

		E5CC-U	E5DC			
Power supply voltage		A in model number: 100 to 240 VAC, 50/60 Hz D in model number: 24	VAC, 50/60 Hz; 24 VDC			
Operating voltage range		85% to 110% of rated supply voltage				
Power consumption		Models with option selection of 000: 5.2 VA max. at 100 to 240 VAC, and 3.1 VA max. at 24 VAC or 1.6 W max. at 24 VDC All other models: 6.5 VA max. at 100 to 240 VAC, and 4.1 VA max. at 24 VAC or 2.3 W max. at 24 VDC	4.9 VA max. at 100 to 240 VAC, and 2.8 VA max. at 24 VDC or 1.5 W max. at 24 VDC			
Sensor input		<ul> <li>Temperature input Thermocouple: K, J, T, E, L, U, N, R, S, B, W, or PL II Platinum resistance thermometer: Pt100 or JPt100 Infrared temperature sensor (ES1B): 10 to 70°C, 60 to 120°C, 115 to 165°C, or 140 to 260°C</li> </ul>				
		<ul> <li>Analog input Current input: 4 to 20 mA or 0 to 20 mA</li> <li>Voltage input: 1 to 5 V, 0 to 5 V, 0 to 10 V,or 0 to 50 mV</li> <li>(The 0 to 50 mV range applies to the E5CC-U only for those manufactured in May 2014 or later.)</li> </ul>				
Input impedance	:e	Current input: 150 $\Omega$ max., Voltage input: 1 M $\Omega$ min. (Use a 1: 1 connect	tion when connecting the ES2-HB/THB.)			
<b>Control method</b>		ON/OFF control or 2-PID control (with auto-tuning)				
Indication accuracy (at the ambient temperature of 23°C) (When mounted individually for E5DC)		Thermocouple: $(\pm 1\% \text{ of indication value or } \pm 2^{\circ}\text{C}$ , whichever is greater) $\pm 1$ digit max. <sup>-1</sup> Platinum resistance thermometer: $(\pm 0.2\% \text{ of indication value or } \pm 0.8^{\circ}\text{C}$ , whichever is greater) $\pm 1$ digit max. Analog input: $\pm 0.2\% \text{ FS} \pm 1$ digit max.	Thermocouple: $(\pm 0.3\% \text{ of indication value or }\pm 1^\circ\text{C}$ , whichever is greater) $\pm 1$ digit max. <sup>*1</sup> Platinum resistance thermometer: $(\pm 0.2\% \text{ of indication value or }\pm 0.8^\circ\text{C}$ , whichever is greater) $\pm 1$ digit max. Analog input: $\pm 0.2\% \text{ FS }\pm 1$ digit max. CT input: $\pm 5\% \text{ FS }\pm 1$ digit max.			
Auto-Tuning		Yes, 40%/100% MV output limit selection. When using Heat/Cool: Independent Heat & cool PID can be set by Auto-tuning.				
Self-Tuning		Yes				
Control output	Relay output	SPDT, 250 VAC, 3 A (resistive load), electrical life: 100,000 operations, minimum applicable load: 5 V, 10 mA (reference value)	SPST-NO, 250 VAC, 3 A (resistive load), electrical life; 100,000 operations minimum applicable load: 5 V, 10 mA (reference value)			
	Voltage output (for driving SSR)	Output voltage 12 VDC ±20% (PNP), max. load current: 21 mA, with short-circuit protection circuit				
	Linear current output	4 to 20 mA DC/0 to 20 mA DC, load: 500 $\Omega$ max., resolution: approx. 10,000				
Auxiliary output	Number of outputs	1 or 2 (depends on model)	2 (depends on model)			
	Output specifications	SPST-NO relay outputs, 250 VAC, Models with 1 or 2 outputs: 3 A (resistive load), or Models with 3 outputs: 2 A (resistive load), Electrical life: 100,000 operations, Minimum applicable load: 10 mA at 5 V (reference value)	SPST-NO relay outputs, 250 VAC, 2 A (resistive load), Electrical life: 100,000 operations, Minimum applicable load: 10mA at 5V (reference value)			
Event input	Number of inputs	-	1 (depends on model)			
	External contact input specifications	-	Contact input: ON: 1 k $\Omega$ max., OFF: 100 k $\Omega$ min.			
		-	Non-contact input: ON: Residual voltage: 1.5 V max., OFF: Leakage current: 0.1 mA max.			
		-	Current flow: Approx. 7 mA per contact			
Setting method		Digital setting using front panel keys				
Indication meth	nod	11-segment digital display and individual indicators				
Multi SP		Up to eight set points (SP0 to SP7) can be saved and selected using the event inputs, key operations, or serial communications.	Up to eight set points (SP0 to SP7) can be saved and selected using the event inputs, key operations, or serial communications. <sup>12</sup>			
Other functions		Manual output, heating/cooling control, loop burnout alarm, SP ramp, other alarm functions, heater burnout (HB) alarm (including SSR failure (HS) alarm), 40% AT, 100% AT, MV limiter, input digital filter, self tuning, robust tuning, PV input shift, run/stop, protection functions, extraction of square root, MV change rate limit, logic operations, temperature status display, simple programming, moving average of input value, and display brightness setting				
Ambient operating temperature		-10 to 55°C (with no condensation or icing), for 3-year warranty: -10 to 50°C with standard mounting (with no condensation or icing)				
Ambient operating humidity		25% to 85%				
Annulent operat		-25 to 65°C (with no condensation or icing)				
Storage temper	rature					
		Front panel: IP50, Rear case: IP20, Terminals: IP00	Main unit: IP20, Terminal unit: IP00			
Storage temper	ection	· · · · · ·	Main unit: IP20, Terminal unit: IP00			

Note: \*1. The indication accuracy of K thermocouples in the -200 to 1,300°C range, T and N thermocouples at a temperature of -100°C max., and U and L thermocouples at any temperatures is The indication accuracy of K thermocouples in the 200 to 1,500 c hange, i and K thermocouples at a temperature of 100 c max, and o and L thermocouples at ally temperature of 400 to 800°C is ±3°C max. The indication accuracy of the B thermocouples at a temperature of 400 c max is not specified. The indication accuracy of B thermocouples at a temperature of 400 c max. is ±3°C ±1 digit max. The indication accuracy of W thermocouples at a temperature of 200°C max is ±3°C ±1 digit max. The indication accuracy of W thermocouples is (±0.3% of PV or ±3°C, whichever is greater) ±1 digit max. The indication accuracy of PL II thermocouples is (±0.3% of PV or ±2°C, whichever is greater) ±1 digit max.
 \*2. Only two set points are selectable for event inputs.



#### E5GC/E5CC/E5EC/E5AC/E5CC-U/E5DC optional tools

Option	Order code
USB based configuration cable	E58-CIFQ2, E58-CIFQ2-E (for E5GC/E5EC/E5AC/E5DC)
PC based configuration and tuning software	EST2-2C-MV4

Refer to the *E5*\_*C*/*E5*\_*C*-*T Digital Temperature Controllers Datasheet* (Cat. No. H177) for details.

OMRON Corporation Industrial Tokyo, JAPAN Contact: www.ia.om	Authorized Distributor:	
<b>Regional Headquarters</b> OMRON EUROPE B.V. Wegalaan 67-69-2132 JD Hoofddorp The Netherlands Tel: (31)2356-81-300/Fax: (31)2356-81-388	OMRON ELECTRONICS LLC One Commerce Drive Schaumburg, IL 60173-5302 U.S.A. Tel: (1) 847-843-7900/Fax: (1) 847-843-7787	
OMRON ASIA PACIFIC PTE. LTD. No. 438A Alexandra Road # 05-05/08 (Lobby 2), Alexandra Technopark, Singapore 119967 Tel: (65) 6835-3011/Fax: (65) 6835-2711	OMRON (CHINA) CO., LTD. Room 2211, Bank of China Tower, 200 Yin Cheng Zhong Road, PuDong New Area, Shanghai, 200120, China Tel: (86) 21-5037-2222/Fax: (86) 21-5037-2200	© OMRON Corporation 2011-2014 All Rights Reserved. In the interest of product improvement, specifications are subject to change without notice. CSM 8 1 0614 Cat. No. H176-E1-06 0614(1111)